MOTO GÄSMx

Direction For Use:
(A) Match code operating instructions.
Power on controller in 3 seconds. First press "C" key to match code. The load
Light will flash 3 times when match code has been successful. It only can match
Once before power off. If you need match code again then you power off
and on again. This controller has power-fail memory.

(B) Remote instructions.
This remote has 4 buttons.

"C" Turn on / off key at any static.

"D" Mode switch. S modes circulating with 1-8 dynamic modes.
This creates static modes?

"A" Mode 1-8. press each time
Increase speed 1-10 levels.

"B" 1-8 press time speed reduces 1-10 levels.

"C" Mode Table:
1-quick flash
2-breathing mode
3-fading in and out
4-rapid fading in and out
S-half fade
6-two-thirds fade
7-a third fade
8-flash